

# Change log for Micromite MMBasic Ver 5.05.05 RR

## New Features:

- When addressing 7-bit I<sup>2</sup>C devices the address range has been expanded to 00 to 7F (hex). Note that this includes some illegal addresses in the strict interpretation of the I<sup>2</sup>C specs.
- In the PWM command the duty cycle can be specified as a negative integer and that value will be directly loaded (as a positive number) into the OCxRS register of the output compare module without scaling or error checking.

## Bug Fixes:

- Fixed a bug that caused a space to be added after and REM command every time a program was edited using EDIT.

# Change log for Micromite MMBasic Ver 5.05.05

## New Features:

- The firmware will now recognise the codes generated by some old Linux terminal emulators for the keys F1, F2, F3 and F4.

## Bug Fixes:

- Fixed a bug that, in some cases, could cause a Syntax Error when an expression was surrounded by brackets.

## Bug Fixes (Micromite Plus):

- A GUI switch that is not a toggle switch will now correctly respond to touch.

# Change log for Micromite MMBasic Ver 5.05.04

## New Features:

- The 28 and 44-pin standard Micromites can now change the clock speed to 1MHz or 0.5MHz using the CPU command and thereby reduce power consumption to as little as 1mA. The BASIC program will run noticeably slower and the following commands and features will not work; tick timers, I<sup>2</sup>C, PULSE, TEMPR(), IR and frequency/period measurement. COM2: will not work and the other ports (serial, SPI, PWM, etc) will have their maximum speed severely limited. At 1MHz the maximum console speed is 4800 baud and at 0.5MHz it is 2400 baud.
- The STRING\$() function will now accept integer or float variables or expressions for the second argument (the ascii value). Previously it would only accept a constant.

## Bug Fixes:

- Corrected two bugs which could cause a STATIC declaration to fail with "Error: Conflicting variable type" or "Error: Out of memory".
- Fixed a bug that caused an error when an array with eight dimensions was declared.
- Fixed a bug that caused identically named static variables in different interrupt subroutines to be corrupted.
- Fixed a trivial bug that could cause an error message to be truncated.
- Fixed a bug that corrupted static variables when a function was called in the parameter list for the subroutine or function that used the static variables.

- Fixed a bug that could cause the READ command to read incorrect data. As a side effect READ will now execute much faster when there are many DATA statements.
- Fixed a bug that could cause SELECT CASE to fail with a string select value.
- When closing a PWM channel MMBasic will now check that each PWM output is in use as a PWM output before resetting the configuration of the I/O pins.

#### **Bug Fixes (Micromite Plus):**

- Fixed a bug that caused GUI BITMAP to incorrectly display a bitmap with uneven width and/or height.
- When the GUI SWITCH control is drawn as a toggle switch now only the highlighted portion of the switch is sensitive to touch (previously it was the whole switch).
- Fixed a bug which caused the legend in the GUI Circular Gauge to display incorrect colours.

## **Change log for Micromite MMBasic Ver 5.05.03**

#### **New Features:**

- Added support for some TFT ILI9341 type displays that require the colour signals to be inverted to display the correct colours. To do this you need to specify the display type as ILI9341\_I in the OPTION LCDPANEL command. Other than this the inverted LCD panel will work the same as the standard panels.
- Increased error checking for single line IF .. THEN .. ELSE .. statements and SUBROUTINE or FUN declarations without a corresponding END.
- Reduced the maximum number of nested FOR...NEXT and DO...LOOP structures to 10 (previously this was 15). This was done to recover some much needed RAM.

#### **Bug Fixes:**

- Sometimes error messages and the string MM.ErrMsg\$ contained unexpected characters such as \$, @ and %. This has been corrected.
- Fixed a bug which interfered with displaying text at the bottom of a ILI9341 LCD screen. In some cases this bug also caused the ILI9341 controller to reboot.
- Suppressed non significant zeros after the decimal point when printing a number in scientific format or when converting it to a string using STR\$().
- Corrected an error in DATE\$ when the date rolled over to the 1<sup>st</sup> March in a leap year (thanks to TassyJim).
- Implemented a fix by Robert Rozee which corrected a small error when converting some floats to integers. This affected STR\$(), HEX\$() and CINT() amongst others.
- When RUN (without a file name) is used within a program the processor and program in flash is completely restarted to avoid any side effects caused by the previous execution of the program.
- Correct an issue with the SoftReset() function called from a CFunction or CSub.

#### **Bug Fixes (Micromite Plus):**

- Fixed an issue which caused the LOAD command to generate an error.
- Fixed an issue with initialising COM4:.  
OPTION CONSOLE OFF or ON will now cause a reboot and is recalled on startup.

# Change log for Micromite MMBasic Ver 5.05.02

## New Features:

- Optimised the storage of programs in flash memory. In the standard Micromite (28 and 44-pin) large programs will have an extra 2KB to 4KB of free program memory space while the Micromite Plus will have up to an extra 8KB free space compared to V5.05.01.
- Added the command AUTOSAVE CRUNCH. This instructs MMBasic to remove all comments, blank lines and unnecessary spaces from the program before saving. This can be used on large programs to allow them to fit into limited memory. CRUNCH can be abbreviated to the single letter C.
- Added the command XMODEM CRUNCH. This acts the same as XMODEM RECEIVE except that it "crunches" the program in the same manner as AUTOSAVE CRUNCH.
- An interrupt on a serial port can now be triggered when a certain character has been received. The number used in the fifth field in the comspec string can now be prefixed with an equals character (=) and in that case MMBasic will call the interrupt subroutine when a character with that ASCII value has been received. For example, using the following comspec string "COM1: 300, 256, MyInt, =13" will cause MMBasic to call the interrupt subroutine MyInt when a carriage return character (ASCII value of 13) was received. The previous behaviour with an ordinary number (ie, interrupt on the number of characters received) is unchanged.
- When a serial port is closed MMBasic will now wait for any data in the transmit buffer to be sent before shutting off the port. Previously the port would have been closed immediately and any characters in the buffer would have been discarded.
- When using the built in EDIT command with Tera Term, Putty, MMEdit and GFXterm it is now possible to position the cursor in normal edit mode by left clicking PC's mouse in the terminal emulator's window. This relies on a feature of these programs which reports mouse clicks as an escape code which MMBasic then uses to position the cursor. Other mouse features (scrolling, marking, copy, paste, etc) are not supported. Thanks to Robert Rozee for showing how this could be done.
- Extended PEEK and POKE to operate on MMBasic INTEGER and FLOAT data types (thanks to Peter Mather).
- New features in the Micromite Plus only:
  - Added the command GUI FORMATBOX. This has a popup keypad which can be used to enter a date, time, latitude, etc in a fixed format. For example, it can be used to get a latitude in the format: dd° mm' ss" N/S.
  - On the Micromite Plus the RTC SETTIME command will also accept a single string argument in the format of dd/mm/yy hh:mm. This means the date/time could be entered by the user using a GUI FORMATBOX with the DATETIME2 format.
  - When using the GUI REDRAW ALL command the screen will be completely cleared and all visible advanced GUI controls redrawn. This is useful if the display has been corrupted or it needs to be refreshed. Previously the screen was not cleared, just the controls redrawn.
  - Added the ARC command for drawing arcs on an LCD panel. The format is: ARC x, y, r1, r2, a1, a2, c where x, y = centre r1, r2 = inner and outer radius a1, a2 = start and end angles (degrees) c = colour
  - Added the STR2BIN() and BIN2STR\$() functions written by Peter Mather for converting numbers to/from a binary representation in a string.

### **Bug Fixes:**

- Fixed two bugs associated with VAR RESTORE or VAR SAVE. One was that on a newly flashed chip the VAR SAVE memory area was not properly initialised and the second was that AUTOSAVE and XMODEM did not clear the VAR SAVE memory (now both will clear this memory).
- Fixed a number of issues that occurred when a user defined function was called in the conditional test of a DO WHILE loop or in the parameters of a FOR-NEXT loop.
- A space is now added after the question mark ("?",) shortcut when it is translated into the PRINT command.
- Fixed a bug in STR\$( ) where it did not correctly position the sign when the padding was set to a zero character ("0").
- Exiting EDIT with F2 and no program will now not generate a meaningless error.
- If the TEMPR command is aborted prematurely it will no longer cause an error when the program is re run.

### **Bug Fixes (Micromite Plus):**

- Fixed an issue which prevented GUI REDRAW ALL from redrawing all controls.
- On small displays the GUI NUMBERBOX numeric keypad is now displayed and erased correctly (previously it could corrupt the display). Also fixed an issue where sometimes the invoking box itself was erased from the screen when the number pad was deployed.
- Corrected a bug which could cause a GUI radio buttons in two separate frames to interfere with each other.
- Trying to use LOAD "file" in a program will now generate an error. LOAD "file", R is unchanged can be used both in a program and at the command prompt.
- Improved the handling of non sensible thresholds in the GAGE and BARGAGE controls.
- Removed the ability to have MM.KEYPRESS called from the GUI NUMBERBOX and TEXTBOX controls. There were too many issues with getting this feature to run reliably. This functionality has been partially replaced by GUI FORMATBOX (see above).
- Fixed a bug which prevented GUI HIDE from operating on a page not currently displayed.
- To correct an issue with detecting EOF() the method of handling the end of line terminating characters in text files has changed. When using INPUT or LINE INPUT MMBasic will work correctly with lines terminated by a CR/LF pair or a single LF. This will not affect files written by MMBasic (which normally use CR/LF) but files written with strange combinations such as a single CR or LF/CR should use INPUT\$( ) instead.
- Fixed a small issue with the brightness of a GUI SWITCH caption when depressed.
- Removed a limitation on the filename length when using DIR\$( ).
- The GUI MsgBox( ) function will now wait for any touch to be lifted before taking over the screen.

### **Bug Fixes (Windows/DOS MMBasic):**

- Fixed a number of issues with the LOAD and RUN commands when loading a new program.

# Change log for Micromite MMBasic Ver 5.05.01

## New Features:

- The various OPTION commands for configuring LCD panels, touch, etc can now be embedded in a program. To support this feature a new command, OPTION SAVE has been introduced. This should be placed after the last OPTION command in a program and will trigger a bulk save of all the options that were previously set in the program. For details see the section "Embedding Configuration Options in a Program" in the Micromite User Manual.
- When the Micromite is first powered up it will no longer rewrite its flash memory. This was normally not noticed by users but it sometimes caused a failure of the verify function when a PIC32 was programmed with the Micromite firmware.
- Further optimised the internal memory management in MMBasic. This improves the speed of string operations by up to 10%.
- Variables on the command line of a CFunction or CSub will be automatically created if not previously defined (and OPTION EXPLICIT is not in force).
- New features in the Micromite Plus only:
  - Added the GUI GAUGE and GUI BARGAUGE controls for displaying multicoloured circular and bar gauges.
  - Extended the layout of the GUI TEXTBOX virtual keyboard. Extra keys are a displayed on all layouts including CAN (cancel), Del (delete/backspace) and space.
  - A small change to facilitate loadable LCD drivers for the Micromite Plus that need to act as a console (ie, the console output will appear on the LCD panel).

## Bug Fixes:

- MMBasic will now throw an error in an assignment (LET command) if there is a difference between the number of dimensions expected and declared.
- Fixed a bug which could cause out of memory errors when using a string expression in the parameter list when calling a SUB or FUNCTION. This same issue sometimes caused out of memory errors with CFunctions and GUI controls on the Micromite Plus.
- Updated the PWM and SERVO commands to prevent changes of the frequency causing a glitch on the output.
- Fixed a bug which caused the PWM frequency to be low by up to 1% at high frequencies.
- Fixed a bug which caused INPUT and LINE INPUT to miss the last character when reading from a file that was not terminated by a carriage return or line feed.
- Fixed an invalid error message when OPTION LCDPANEL USER was followed by a permanent option.
- Fixed a problem where an LCD panel remained configured following an error that occurred during its configuration (using OPTION).
- In the Windows/DOS version the Caps Lock key will now not generate extra characters.

## Bug Fixes (Micromite Plus):

- Fixed a bug that disabled the onboard USB interface when an LCD panel using the SPI interface was configured.

- Fixed a bug which could cause a CPU exception when passing an array of floats to a CSUB or CFUNCTION on the Micromite Plus (as done with the Long Strings Library). Note that (as per the documentation) an array of floats is passed as an array of doubles (it is **not** converted to an array of single precision floats).
- Prevented the OPTION DISPLAY command from being used when OPTION LCDPANEL CONSOLE has been set.
- Using SEEK with a file position of less than one will no longer cause a CPU exception. Instead it will just move the file position to the start of the file.
- TOUCH(LASTX) and TOUCH(LASTY) now work as documented (thanks to Peter Mather).
- The FILES command no longer causes subsequent file related commands to ignore errors.
- CTRL-C can now be used to stop a program which has a Message Box on the screen.
- When pressing the enter key (Ent) on a GUI NUMBERBOX the resultant number displayed will be automatically formatted with the same number of digits after the decimal point as the number entered using the keypad.
- Fixed a bug which caused the CtrlVal() function to return an incorrect value for a NUMBERBOX or TEXTBOX when called from within the MM.KEYPRESS subroutine.
- As part of the above fix CtrlVal() will always return a floating point value for NUMBERBOX - even within the MM.KEYPRESS subroutine (previously it was documented as returning a string inside this sub).

## Change log for Micromite MMBasic Ver 5.04.09

### New Features:

- The Micromite Plus now uses double precision floating point (the standard 28 and 44-pin Micromites still use single precision). This means that calculations will have a far greater range and will be accurate to about 16 decimal digits. When printing a floating point number the Micromite Plus will display up to 9 digits (this can be changed with the Str\$() function). CFunctions that manipulate single precision floating point can still be used as MMBasic will convert between the two precisions as needed (with the exception of arrays of floats, see the documentation on CFunctions).
- Implemented the STATIC command which is similar to the LOCAL command except that the variables created will retain their value between calls to the subroutine or function. The syntax is exactly the same as DIM.
- Added the ability to define a display driver in BASIC. See the file "User Display Driver.txt" in the Embedded C Modules folder of the distribution zip for more information.
- Optimised some of the internal memory management in MMBasic. The resulting speed improvement varies from 20% for programs that use no strings to 5% for programs with heavy use of strings.

### Bug Fixes:

- Fixed a bug that caused any assignment to a variable starting with the characters "TIMER" to assign that value to the TIMER counter.
- Fixed a bug that caused an error in a FOR loop when NEXT was not on a line of its own and the loop never executed because the start value was greater than the end value.
- Fixed a bug which prevented VAL() from correctly converting 64-bit numbers.

- Corrected an issue which could cause corruption of the screen image when the Micromite Plus is driving a 5" SSD1963 based LCD display at a CPU speed of 100MHz or greater.
- Fixed a bug which caused ON ERROR SKIP to throw an error if followed by a comment on the same line.
- Changed the speed of the I2CPort CFunction to 100KHz. Previously it was erroneously set to 100Hz. This CFunction can be found in the *Embedded C Modules* folder of the firmware zip file.
- Fixed a bug that caused SELECT CASE to fail with a syntax error if the CASE argument was a constant prefixed with – or +.
- Fixed an issue that caused data corruption on the I<sup>2</sup>C interface (including timeouts) when a simultaneous connection was made to the USB interface (Micromite Plus only).
- Fixed a bug in the TEMPR function that could cause corruption of variables and other data. Thanks to Peter Mather for the fix.
- Fixed a bug that caused the MEMORY command to incorrectly count the memory used by CFunctions. Thanks to Peter Mather for the fix.

## Change log for Micromite MMBasic Ver 5.04.08

### Bug Fixes:

- Corrected a bug which caused EXIT DO to skip the first line after the LOOP command.
- Corrected a bug which caused EXIT FOR to fail if the whole FOR loop was on a single line (with colons as command separators).
- Fixed a bug which could cause out of memory errors when a string was passed to a SUB or FUNCTION.

## Change log for Micromite MMBasic Ver 5.04.07

### Bug Fixes:

- Corrected a bug which could cause the corruption of a string array when it was passed as an argument to a SUB or FUNCTION.
- Fixed a bug which caused the MAX() and MIN() functions to return an incorrect value if any of the arguments were an expression (rather than a variable or constant).
- Fixed a bug which caused the definition of a SUB or FUNCTION to be ignored if it was positioned at the very start of a program.
- Fixed a bug which could cause the function ACOS() to generate an internal error.

## Change log for Micromite MMBasic Ver 5.04.06

### New Features:

- The third parameter of the STR\$( ) function can be negative indicating that the exponential format should always be used.
- Modified the STRING\$( ) function to allow any number in the range of zero to 255 to be specified in the second argument (previously it was printable characters only).

- Some of the internal logic of MMBasic has been rewritten to be more efficient and compact. This should not affect any existing programs but one additional feature is more tolerance for extra spaces (for example, after an array name and before the opening bracket).
- Added a UNI/O driver to the embedded C routines library. This is designed to work with the Microchip 11XX series of low cost EEPROMS.
- Created a DOS version of MMBasic which runs in a console window under Windows XP or greater (incl Win 10). It can be downloaded from: [mmbasic.com/MMBasicForDOS.html](http://mmbasic.com/MMBasicForDOS.html)
- Micromite Plus only:
  - If the DISPLAYBOX or LED controls are touched an interrupt will be triggered and TOUCH(REF) and TOUCH(LASTREF) will be set to their reference number (previously the reference number was not set).
  - OPTION ERROR has been removed from the manual and in a future version will be removed from MMBasic. Its functionality has been replaced with ON ERROR introduced in V5.2 which provides more features.

### **Bug Fixes:**

- Corrected an issue which could corrupt a string that is returned by a function and that function is used in the argument list for another function.
- Fixed a bug in the MAX() and MIN() functions which did not work with negative values.
- Rewrote the SPIPort CFunction in the embedded C routines library to fix issues with word lengths over 31 bits and faulty SPI modes.
- Fixed an issue with the EOF() function when testing the console (ie, #0) where it returned true when characters were waiting in the input buffer (should be false).
- Micromite Plus only:
  - Fixed a bug which sometimes caused the text in a DISPLAYBOX control to be truncated if the line split character (~) was used.
  - Fixed a bug which could cause the caption of a radio button to be updated with an incorrect font.
  - Corrected a number of issues which could cause an invalid font error when updating GUI controls.
  - Rewritten the code associated with using CTRLVAL(\$ref) while a virtual keypad is displayed. This fixed some issues including an error when getting the value of a control that returns a floating point number.
  - Installed a fix for an issue which caused PLAY WAV to pause for a short time after playing a WAV file. Thanks to Peter Mather (matherp) for the fix and code.

## **Change log for Micromite MMBasic Ver 5.04.05**

### **New Features:**

- Relaxed error checking on I<sup>2</sup>C addresses to allow addresses 7 and below to be used.
- ERASE will now also delete non array variables.
- Where the GUI command can operate on all controls (ie, GUI DISABLE ALL) it will now only affect the controls on the current page(s). Previously it affected all pages.

### **Bug Fixes:**



- Corrected a problem that caused the LEFT\$() function to throw an error if asked to return zero characters.
- Fixed a bug that prevented ERASE from deleting some arrays.

## Change log for Micromite MMBasic Ver 5.04.04

### Bug Fixes:

- Corrected an issue that caused out of memory errors with repeated use of TEXT and GUI CAPTION commands. As part of this fix the justify parameter is now checked more carefully and now the sequence of the characters must be the horizontal first followed by the vertical and orientation code (in the MM+) last. One or more of the code letters can be omitted but the sequence must be as above and no other characters are allowed.
- Fixed a bug which caused embedded display drivers to lose their configuration when a program was run.
- Bug fixes in the Micromite Plus only:
  - Rectified a fault which caused the LOAD command to generate an out of memory error.
  - Fixed a bug which prevented XMODEM from saving or reading from a SD card file.
  - Corrected an issue that corrupted the += symbols in font 6.

## Change log for Micromite MMBasic Ver 5.04.01

### New Features:

- Removed the DISTANCE() function and the IR SEND and HUMID commands from MMBasic. These are now distributed as embedded C modules which work exactly the same as the original function/commands in previous versions of the Micromite firmware - see the relevant PDF files which are included in the Micromite firmware zip file under the folder Embedded C Modules.
- The justification field in the TEXT command can now be specified as a string expression and is the preferred method of specifying this parameter. For backwards compatibility the old method of using a simple sequence of characters will still be accepted.
- The TEMPR START command can now start temperature conversions on an unlimited number of I/O pins simultaneously (previously it was limited to one pin at a time).
- Most of the restrictions for using I/O pins which clash with other uses has been removed. So, for example, now it is possible to manipulate the LCD CS pin from within a program using PIN()=. This improves the flexibility of the Micromite but it does require the programmer to be aware of the consequences.
- Implemented MAX() and MIN() functions which will return the maximum or minimum value of a series of numbers.
- The timed CPU SLEEP command can now be terminated early by specifying an optional interrupt pin number. Any change in the state of this pin will terminate the sleep regardless of the amount of time remaining.
- New features in the Micromite Plus only:
  - Replaced the SD card driver with FatFs ported by Peter Mather. This has many benefits over the previous driver:
    - Long file and directory names (yay!) with upper/lowercase characters and spaces.

- Directory paths are supported in file names (eg, \dir1\dir2\fname.txt").
- When no files are open the SD card can be removed and reinserted or replaced without requiring a reboot of the Micromite.
- Read/write is much faster.
- Added the NAME command for renaming files.
- The justification field in the TEXT and GUI CAPTION commands can now specify the orientation of the displayed text as vertical, inverted, rotated 90° clockwise or counter clockwise (thanks to Peter Mather for this feature). See page 25 of the *Micromite Plus Manual*.
- The XMODEM command can now transfer a file to or from a file on the SD card. This is in addition to the standard behaviour of transferring to/from program memory.
- When a WAV file or tone has finished playing (or has been stopped) the PLAY command will leave the PWM output running to suppress audible pops at the end of the play time.
- When a text or number box is touched the pen down interrupt subroutine will now be called **before** the keypad is drawn. This gives the programmer the opportunity to redraw non GUI graphics to accommodate the keypad which is about to appear. When the touch is removed the pen up interrupt will be called after the keypad is removed so that any non GUI graphics can be redrawn. This is a key feature in allowing the mixing of non GUI graphics with GUI controls.
- The virtual keyboard generated when the user touches a Number Box or a Text Box can be dismissed by the program using the commands GUI NUMBERBOX CANCEL or GUI TEXTBOX CANCEL.

### Bug Fixes:

- Fixed a bug which prevented the IR SEND function from working correctly.
- Fixed a bug which caused the EDIT command to sometimes misplace the cursor (thanks to Robert Rozee for the fix).
- Fixed a bug which caused a sub/function parameter to be set to zero when the supplied argument was a different type. Also, now when converting a float argument to an integer rounding will be performed (previously the fractional value was truncated).
- Fixed a bug which caused string arrays to be saved incorrectly using VAR SAVE.
- Fixed the definition of s\_vartbl in CFunctions.h (used for embedded C code only).
- Fixed a bug where the blinking of the GUI LED control could disrupt other graphics operations (like drawing text).

## Change log for Micromite MMBasic Ver 5.03.02

### Bug Fixes:

- Fixed a bug which sometimes caused VAL() to throw an error (thanks to Robert Rozee).
- Fixed the definition of getConsole() in CFunctions.h (used for embedded C code only).
- Bug fixes in the Micromite Plus only:
  - Suppressed the "Touch not calibrated" error for accidental touch on the LCD screen before calibration.

# Change log for Micromite MMBasic Ver 5.03.01

## New Features:

- The format of the version numbers has changed slightly. The minor version number will be two digits and rather than using a letter to indicate a minor release (ie, Ver 5.3A) two digits will be appended to the version number (eg, version 5.03.01). MM.VER will return the version as x.yyyz (eg, 5.0301) which is compatible with the previous behaviour.
- The LIBRARY SAVE command will now add the contents of the program memory to the library while retaining its previous contents (ie, it no longer requires that the library space be cleared first). Repeated use of the LIBRARY SAVE command allows the contents of the library to be built up in stages which is handy if large fonts are being loaded into the library. LIBRARY DELETE works as before (ie, clears the whole library space).
- Optimised the transfer of data to SPI based LCD display panels - screen updates are now 50% faster. Thanks to *matherp* and *Nathan* on The Back Shed forum for showing how it could be done.
- Extended the commands and functions that use a serial I/O file number (eg, EOF(), LOC(), INPUT\$(), etc). Now a file number of zero (eg, #0) will refer to the console.
- Extended the PORT() function so that it will also return the state of output pins (similar to the way that PIN() works).
- Extended ON ERROR SKIP so that the number of commands to skip error checking can be optionally specified (ie, ON ERROR SKIP nn). The default is one, as before.
- Added the ability for a C Routine to add a custom touch driver for LCD display panels.
- On exiting the editor (with colour coding turned on) the editor will restore the previous colour settings used by the terminal emulator.
- Implemented the TRIANGLE drawing command. For the Micromite Plus it is a built in command, for the standard MX170 Micromite it is a CSub which can be embedded in the BASIC program (the CSub is included in the firmware zip file).
- Implemented the GUI RESET LCDPANEL command. This will reinitialise the LCD panel and is useful if the panel had been previously powered down to conserve power.
- Extended the FOR...NEXT loop to accept a floating point number for the STEP value. Note that this should be used carefully as repeatedly adding a fractional number to the floating point variable used in the FOR loop will accumulate rounding errors.
- New features in the Micromite Plus only:
  - Implemented the PLAY command. This will play stereo WAV files stored on the SD card using the I/O pins PWM 2A and PWM 2B. You can also generate precise sine waves with selectable frequencies from 1 Hz to 20 KHz. See the section Sound Output in the updated *Micromite Plus Manual*.
  - On the 64-pin Micromite Plus moved the PWM2B output from pin 47 to pin 32.
  - Implemented transparent text and the BLIT command. Transparent text is invoked by using a background colour of -1 and the BLIT command allows the background image to be saved and then restored allowing moving objects to be displayed over a background image. See the section Basic Drawing Features in the updated *Micromite Plus Manual*.
  - Implemented the PIXEL() function for reading the colour of a pixel on an LCD screen capable of supporting transparent text.

- Implemented the GETSCANLINE() function. For LCD panels using the SSD1963 controller this function returns the current scan line that is being refreshed. Using this a BASIC program can time its writes to the LCD panel to avoid flickering.
- Implemented a new USB stack (called M-Stack) ported to the Micromite by Peter Mather (*matherp* on the Back Shed forum). The functionality is the same but the speed of data transfer (particularly XModem) is faster.
- Added the EVAL() function. This will take a string which represents an expression, evaluate it and return the resultant value.
- The GUI LED can now be instructed to flash, ie, turn on for a short time then automatically turn off. This is accomplished by setting the value of the LED (using CtrlVal(#ref) = ) to the number of milliseconds that it should remain on. As before, setting its value to one will turn it permanently on and zero will turn it off.
- Added the GUI AREA control. This will define an invisible area of the screen that is sensitive to touch and can be used as the basis for creating custom controls that are assembled and managed by the BASIC program.
- The Number Box and Text Box controls will now call the subroutine MM.KEYPRESS (if it exists) after most key presses. The control's reference number (an integer) and the caption on the key (a string) are supplied as parameters and using these the subroutine can inspect the current contents of the control and change it on the fly using CtrlVal(#ref).
- Added the decimal point and degree symbols to Font #6. The degree symbol is the back quote character (60 hex or 96 decimal).
- All strings used in GUI controls can now display multiple lines by using the tilde character (~) to separate each line in the string. For example, a push button's caption can be "ALARM~TEST" and this would be displayed on the button's face as two lines.
- The separator character between lines in a MsgBox has been changed to the tilde character (~) to match the above feature (previously it was the vertical bar).
- When calibrating a touch screen the accuracy of the calibration will be reported on the console and the LCD display panel.
- The state of the SD Card Card Detect and Write Protect pins can now be read using the PIN() function. The same for the touch IRQ pin.
- The PS2 keyboard will now start up with Num Lock off.
- For radio buttons and check boxes the touch sensitive area has been extended to include their associated caption.
- The OPTION CONTROL nn command can be used to change the number of GUI controls allowed (the default is still 100).
- Improved the speed of loading an image when using LOAD IMAGE. Thanks to *matherp* and *Nathan* on The Back Shed forum.
- Increased the maximum number of subroutines and functions in a program to 200.

The TRIANGLE, PLAY and BLIT commands, the PIXEL() and GETSCANLINE() functions and the transparent text functionality were written by *Nathan* and/or *matherp* on [The Back Shed](#) forum.

## Bug Fixes:

- Fixed a bug introduced in Beta 3 which caused an MIPS exception on the MX170 version when reading from a serial port.
- Fixed a bug which caused VAL() to sometimes return a float when it should have returned an integer (thanks to Robert Rozee for the fix).
- Fixed a bug which caused PEEK and POKE to corrupt the variable table if used to access a non-existent variable.
- Fixed a bug where, if the x and y axis of touch were reversed (which is allowed), you would get a warning message, even if your calibration was accurate.
- Fixed a bug which could generate an error when opening a COM port if the previous open had failed due to an invalid file number.
- Fixed a bug which caused errors when a user-defined function was embedded in an expression passed to another user-defined function.
- Corrected a bug which caused the OPTION RESET command to not reset all options.
- Fixed a bug which caused ON ERROR SKIP or IGNORE to clear all variables if an error was ignored in the main program (ie, not in a subroutine).
- The read-only variable MM.OneWire is now reset when a program starts running.
- Worked around an issue with the PIC32 that caused the sleep current to increase by ten times at random times during sleep – now the chip will remain in deep sleep with a current of about 40µA (MX170 version). Updated the *Micromite User Manual* (page 15) with hints on how to reduce the sleep current.
- In the long strings CFunction library fixed an issue with SInstr() which occurred if the search string was longer than the long string.
- Bug fixes in the Micromite Plus only:
  - Fixed a bug where a file error would return the value of 16 for MM.ERRNO.
  - Fixed an inconsistency with the SPINBOX control which could be caused when the initial displayed value was not within the max/min range.
  - Corrected a bug where the Number Box and Text Box controls did not correctly set the TOUCH(LASTREF) value when exiting the control.
  - Fixed a bug in the Radio Button and LED controls where the control was not drawn on the centre of the X and Y coordinates and the radius was treated as the diameter. Unfortunately fixing this bug will cause the Radio Button and LED controls in programs written for 5.2 to require adjustment.
  - Corrected a bug which caused the editor's cursor to erase the underscore character on an LCD screen when it is acting as the console.
  - The Number Box and Text Box controls will now correctly erase the background to the current background colour.
  - Fixed an issue where radio buttons inside a frame on one page could be controlled by a frame on another page.
  - When a control is disabled it will now correctly respect the current background colour.
  - Restored the OPTION ERROR CONTINUE/ABORT command. This has been largely superseded by the ON ERROR command but can still be used by old programs.

## Change log for Micromite MMBasic Ver 5.2

- Implemented the ability to manage program errors. ON ERROR IGNORE will ignore all errors, ON ERROR SKIP will ignore an error in the next statement only and ON ERROR ABORT (the default) will abort on any error. MM.ErrNo will be non zero for an error and MM.ErrMsg\$ will contain the error message. Both can be cleared by ON ERROR CLEAR.
- Micromite Plus:
  - Implemented the MsgBox() function. This will display an ad hoc dialog box with program defined message and buttons. When the user selects one of the buttons any on screen controls will be restored and the function will return the number of the button pressed.
  - Implemented the GUI SETUP and PAGE commands which allows the GUI controls to be organised into pages that can be quickly hidden or displayed. This makes it much easier to write programs which need to switch between various screen displays.
  - The GUI DEFAULT command has been removed as its functionality is now provided by the GUI SETUP command.
  - You can now disable, hide or even delete a control while it is active (ie, from within the touch down interrupt). You can also change its colour and other attributes.
  - CPU speeds of 20MHz, 10MHz and 5MHz can now be selected.
  - Fixed a bug that would intermittently cause an exception or hang when switching the CPU speed from 60MHz or lower to 80MHz or higher.
  - Removed the LOAD FONT command (DEFINEFONT achieves the same outcome).
  - Changed the error message when trying to open SPI2 and it is already in use for a SPI display, touch or the SD card.
- Replaced the back quote (`) character with the degree symbol (°) in all built-in fonts except Font #6.
- Added the functions ACOS() and ASIN().
- CFunction changes (for both the Micromite and Micromite Plus):
  - Improved the CSub/Crunction syntax so that the type of parameters and the returned value can now be specified in the CSub/CFunction definition.
  - Implemented the ability for a CFunction to execute a BASIC subroutine from within the CFunction. This subroutine can contain nested calls to other subroutines and functions. Amongst other things this allows any MMBasic command to be run by a CFunction.
  - In the CallTable[] used by CFunctions added pointers to SaveProgramToFlash, error(), ProgFlash vartbl and varcnt. These will allow CFunctions to read/write program memory, use the standard error routines built into MMBasic and lookup (and even change) variables defined in the BASIC program.
  - Implemented the ability for CFunctions to hook into the Interrupt 2 handler.
- The RTC SETTIME command will accept a full year (eg, 2016) or an abbreviated year (eg, 16) and it will also automatically set the Micromite's internal clock.
- Increased the internal stack space used by MMBasic. This allows much more complex expressions which previously caused an "Expression is too complex" error.
- If an error or conflict due to an OPTION setting occurs at startup a suitable message will be displayed and the offending OPTION setting will be cleared. Previously the Micromite could be stuck in an endless series of reboots.

- Fixed a number of bugs in Str\$() that caused incorrect formatting. This function now always places the sign after any padding characters.
- Changed CPU SLEEP to make the sleep time more accurate and update the Timer correctly.
- Changed the exponentiation operator so that it traps a floating point overflow.
- Corrected a bug which caused PWM channel 1 to not operate correctly on power up.
- Fixed a bug that could cause the editor to lose track of the cursor's position.
- Corrected two bugs that caused a corrupted program when some specific line numbers were used on an otherwise empty line.
- Fixed a bug where closing COM2 did not release the Tx line.
- Fixed a bug which prevented a CFunction from returning a float.
- Fixed a bug which cause the wrong date/time to be returned when the OPTION RTC pins were the same as the normal I<sup>2</sup>C pins.
- Fixed a bug which caused small negative numbers to print without the negative symbol. This also affected the STR\$() function.
- Fixed a bug that caused strange error messages in complex programs with nested subroutines that in turn used nested FOR loops or DO loops that were often exited with END SUB or END FUNCTION (phew!).
- Saved variables will be automatically cleared when the NEW command is used but not when EDIT, AUTOSAVE and XMODEM are used.
- Corrected an issue that could cause the Timer and other internal clocks to lose time when repeatedly switching CPU speeds.
- Corrected a bug in the BOX and RBOX commands which drew a box with dimensions in error by one pixel.
- Fixed a bug that caused the program saved in the library to be truncated when the LCase\$(), Len() or Mid\$() functions were used in the argument list of a user defined subroutine.
- Modified the SERVO command so that it can accept rapid updates while still generating a valid servo signal.
- Fixed a bug which caused the RTC command to close the I<sup>2</sup>C channel if it was open before the command was used.
- Updated the IR command in the Micromite User Manual to document the fact that the bits returned in 'dev' and 'key' for the NEC protocol are reversed

## Change log for Micromite MMBasic Ver 5.1

- Modified the way that VAR SAVE works:
  - It can now be used repeatedly adding to the list of saved variables. Variables that had been saved previously will be updated with their new value, any new variables (not previously saved) will be added to the saved list for later restoration.
  - Arrays can also be saved. They are specified with empty brackets. eg, var()
  - A new command VAR CLEAR can be used to erase all saved variables.
  - The saved variables will be automatically cleared when a new program is loaded or a program is edited using EDIT.

- Implemented the TRACE command. TRACE ON and TRACE OFF work the same as TRON and TROFF (now superseded). Micromite Plus only: TRACE LIST nn will list the trace of the last nn lines executed (note that TRACE ON is not required for this to work).
- Micromite Plus only: A new command OPTION RTC allows the I/O pins for the RTC command to be specified (they may be any pair of I/O pins). If this command is used MMBasic will automatically get the correct time from the RTC on power up or restart.
- Added the ability for CFunctions to use Timer 1 and Timer 5 (on the Micromite Plus).
- If an argument to a CSub or CFunction resolves to a float it will be passed as a float. Previously it was converted to an int.
- MM.VRes and MM.HRes will return zero if a display is not configured (previously it caused an error).
- Text characters can be drawn partially off and on the screen and in that case the part on the screen will be drawn correctly (previously the character was ignored).
- MMBasic will now throw an error if a variable is declared twice using DIM or LOCAL.
- For compatibility with Microsoft BASIC a trailing comma in a print statement will now suppress the automatic generation of carriage return and line feed characters.
- When drawing text on the LCD a space character in font #1 will be drawn as a blank character. Previously it was drawn as a blank rectangle.
- The LOG() function will now throw an error if passed a negative argument.
- Standard (MX170) Micromite:
  - An interrupt previously set on the touch IRQ pin can now be cancelled.
  - The console input buffer has been increased to 128 bytes.
  - Corrected an issue that caused some characters to be lost when a large program was loaded using AUTOSAVE.
- Micromite Plus:
  - An error will now be thrown if an active GUI control is deleted or hidden.
  - Added the 'Can' button (cancel the change) to the number and text boxes. Changed the caption on the delete button from '<<<' to 'Del'.
  - The caption for a frame can now be updated using CTRLVAL(ref) =
  - Swapped the up down arrows on the spin box.
  - Fixed an issue where the spin box could freeze on repeated up/down button presses.
  - Using CLS (clear screen) will also automatically hide any visible GUI controls.
- Fixed a bug where a bracket in a string argument to a function could cause an error.
- Fixed a bug that sometimes caused LIBRARY SAVE to corrupt the library.
- Fixed a bug which caused labels in the library to be hidden.

## Change log for Micromite MMBasic Ver 5.0

- Added support for ILI9341 based LCD panels. These are low cost colour LCD displays with 2.2 inch to 2.8 inch diagonal size and 240x320 pixels. From within MMBasic the programmer can change fonts and colours, draw text, lines, boxes, circles, etc.



- ILI9341 based LCD panels also include a touch controller and MMBasic provides full support including touch detection and reporting the touch coordinates in pixels.
- Support for many additional LCD panels can be loaded as embedded C modules. These are distributed in the "Embedded C Modules" folder in the Micromite firmware zip file.
- Additional fonts can be loaded as part of a BASIC program. These are distributed in the "Embedded Fonts" folder in the Micromite firmware zip file.
- The Library feature has been added. This allows BASIC code and CFunctions to be copied into a hidden area where they essentially become extensions of the MMBasic language. Programs saved to the Library area are also compressed saving on program flash space.
- Using the Library feature it is now possible to have a section of BASIC code which is run immediately before the main program is run. This allows constants and hardware features to be set up regardless of the program that is loaded into main memory.
- The functions MM.PROMPT and MM.STARTUP (if they exist) will be run immediately before the prompt is displayed and when the Micromite first starts up. This can be useful for changing the prompt, setting defaults and loading hardware drivers.
- The built in editor's output can be configured to be colour coded. When this is enabled keywords, text, numbers, comments, etc will be displayed in different colours.
- Implemented OPTION LIST and OPTION RESET commands. The first will list all saved options that have been changed from their defaults while the second will reset them all to their original defaults.
- Introduced numerous changes to CFunctions to allow them to load display drivers, hook into some MMBasic internal functions and more. A large range of embedded C modules are available including some that add additional serial, I<sup>2</sup>C and SPI ports to MMBasic. These are distributed in the "Embedded C Modules" folder in the Micromite firmware zip file. The folder also contains a tutorial and the tools needed to create embedded C modules.
- Added the commands CONTINUE FOR and CONTINUE DO to the BASIC language. These will cause MMBasic to skip to the end of the loop and continue program execution.
- Interrupts can now be set on any I/O pin up to a maximum of ten simultaneous interrupts. Because any pin can be used the INT designation has been removed from the pinout diagrams.
- Weak pullups can be specified on the I<sup>2</sup>C data and clock lines by appending the option ",PU" to the end of the I2C OPEN command.
- Renamed the DS18B20() function and DS18B20 START command to TEMPR() and TEMPR START. Also, renamed the DHT22 command to HUMID. The old names can be still used but will be removed in some future version.
- Fixed a bug which caused the internal clock to run fast when CPU 5 was used.
- Fixed a bug which caused the PULSE command to throw an error when PULSE pin, 0 was used to terminate a currently running pulse.

## Change log for Micromite MMBasic Ver 4.6c

- Removed the ability to read the internal reference using PIN(0). Due to issues in the PIC32MX170 chip this function would occasionally cause the Micromite to restart without warning.

- Changed the reset function which can be invoked at startup (originally shorting the console Tx and Rx pins). The new routine requires a stream of exclamation marks on startup. See the section "Micromite Special Features" in the user manual for details.
- Modified the RESTORE command so that the starting line number for the READ command can be specified.
- Corrected a bug which could cause a processor exception when a leading + or – was used to prefix a constant number.

## Change log for Micromite MMBasic Ver 4.6b

- Extended the IR command so that it will work with either NEC or Sony remote controls. The NEC protocol support includes both standard and extended addressing. The IR command syntax is exactly the same as in previous versions, the only change is that it will automatically detect and decode whatever remote control protocol (NEC or Sony) is being used at the time.
- Extended the RTC command to work with Maxim/Dallas chips including the DS1703, DS3231 and DS3232. This is in addition to the Philips PCF8563 which is already supported. The RTC command syntax is exactly the same as in previous versions, the only change is that it will automatically detect and use whatever chip is connected to the I<sup>2</sup>C pins.
- Added the RTC SETREG and RTC GETREG commands to set and read the registers in a real time clock chip. These commands are not necessary for normal operation but they can be used to manipulate special features of the chip (alarms, output signals, etc). They are also useful for storing repetitive temporary information in the chip's battery backed RAM when the SAVEVAR command is not suitable.
- Changed the OPTION LINES command to OPTION DISPLAY. The new command can set both the number of lines on the display (as did the old command) but also the width of the display in characters. This means that the EDIT command can now be used with the VT100 ASCII Video Terminal (<http://geoffg.net/terminal.html>) in composite video mode.
- The watchdog flag (MM.WATCHDOG) is now cleared by the RUN and NEW commands.
- Fixed a bug which caused the DHT22 command to return an invalid reading at low temperatures.
- Corrected a bug which caused the SPI READ command to return incorrect data when used immediately after a SPI WRITE command.
- Fixed a bug that sometimes caused a comparison between two integers to return an invalid result when the value of either integer was greater than 30 bits (ie, +/- 1073741823).

## Change log for Micromite MMBasic Ver 4.6

- **IMPORTANT:** Ver 4.6 (and later versions) will only work with the PIC32MX170F256 or PIC32MX270F256 series of chips (see the Micromite MkII manual for the details). This is different from the previous version which ran on the PIC32MX150 series of chips.
- **IMPORTANT: Only one hex file is supplied.** The Micromite MkII hex file will work with either the 28 or 44-pin versions of the MX170 chip and will automatically configure itself to deal with the different pin outs. This is unlike previous versions that required a different hex file for each chip.
- Compared to version 4.5 on the PIC32MX150 series of chips the free flash memory for program storage is now 60K (up from 20K). The free RAM available for variables and buffers is now 52K (up from 22K).

- The extra flash memory in the Micromite MkII has also been used to optimise MMBasic for speed (rather than size as with previous versions). As a result a typical BASIC program will now run about 40% faster at the same CPU speed.
- An additional data type (64-bit integers) is now available. These can be used to store and manipulate numbers as large as 19 digits or  $\pm 9223372036854775807$  without loss of accuracy (as against floating point which has a limit of 6 to 7 significant digits). Integer arithmetic is also about 25% faster than floating point. Integers can be specified by adding the suffix "%" to a variable's name (eg, count%, j%, etc) and by using constants without a decimal point. See the section "Defining and Using Variables" in the User Manual for more details.
- Implemented the full SELECT...CASE structure according to the ANSI Standard for Full BASIC (X3.113-1987) or ISO/IEC 10279:1991 (also used by Microsoft in Visual Basic). This provides for tests like: CASE -11 TO 4, 8 TO 12, 51, 23, IS > MaxNbr  
It also allows an unlimited number of CASE statements and unlimited nesting of SELECT...CASE structures within other SELECT...CASE statements.
- Implemented the ability to embed a compiled C or assembler program (called a CFunction) into a BASIC program. This provides the ability to perform particular high speed processing or gain access to the specialised features of the PIC32 chip using an efficient compiled language.
- Implemented the DHT22 command to read the temperature and humidity from a DHT22 temperature/humidity sensor. This device is also known as the RHT03 or AM2302. See the section "Measuring Temperature and Humidity" and the DHT22 command in the User Manual for details.
- Added a new command OPTION EXPLICIT. This will prevent MMBasic from automatically creating a variable when first referenced. Placing this command at the start of a program will require that every variable be explicitly declared using DIM or LOCAL which in turn will draw attention to misspelt variables (a common programming error).
- The default type for a variable which is not explicitly defined can be set with OPTION DEFAULT type where 'type' can be either FLOAT, INTEGER, STRING or NONE. See the "OPTION DEFAULT" entry in the manual.
- Floating point variables can now be specified with the suffix "!". ie, float! = 2.34
- The DIM command has been extended to allow the variable's type to be set without needing a suffix. ie, DIM STRING str1, str2, name, etc. It will also allow the Microsoft convention of: DIM str AS STRING, nbr AS INTEGER, etc
- The DIM command can also initialise a variable when it is created. For example:  
DIM STRING str = "Hello World".
- Arrays can also be initialised when declared using the DIM command. The syntax is:  
DIM var(d1, d2, etc) = (init1, init2, init3, init 4, etc)  
See the DIM command for more details and examples.
- Added the CONST command to define a constant. This will act like a variable but cannot be changed. For example: CONST TestPin = 5.
- Implemented OPTION CLOCKTRIM to fine tune the frequency of the internal oscillator which is used as the basis for all timing (date, time, PWM, serial I/O, etc).
- Added the >> and << operators to shift right and shift left the bits in an integer by a certain number of bits. See the section "Operators and Precedence" in the User Manual.
- Added the ability for the CPU SLEEP command to put the processor to sleep for a specified number of seconds (from one second to 10 days) without any external circuitry.

- The SETPIN command has been enhanced with an option to specify the gate time to be used when making frequency measurements. Now the gate time can be any number from 10ms to 100 seconds. See the SETPIN command for more details.
- The SETPIN command and PIN() function have been enhanced to allow the period measurement function (PIN) to return the average period over a number of cycles.
- The SETPIN command now has an option to select an internal pull up or pull down resistor on an I/O pin when configured as a digital input. If the option is not selected the input will float (as before). See the SETPIN command for more details.
- Added the option "OC" to the SETPIN x, DOUT command. This option will set the output to open collector. The old SETPIN x OOUT command will still be recognised for backwards compatibility.
- The PIN() function will now return the value on the output of a pin configured as a standard digital output. This is in addition to its previous ability to read the output of a pin configured as open collector.
- When used to read pin 0 the PIN() function will measure the voltage of the internal voltage reference (nominally 1.2V). Note that pin 0 does not have to be configured via SETPIN. Because the reading will vary with the supply voltage on the Analog Power pin this measurement can be used to infer the supply voltage to the Micromite which in turn can be used to adjust readings made on the standard analog inputs to compensate for voltage variations (eg, when running on battery power). See the section "Analog Inputs" in the manual for a full description.
- The echoing of characters received at the console can be turned off and on. This is useful when the console is used as a third general purpose serial port. See the command OPTION CONSOLE ECHO.
- The polarity of the console transmit and receive lines can be inverted with the OPTION CONSOLE INVERT command. The OPTION CONSOLE AUTO command will specify that the console serial input/output is to be automatically inverted if the console Rx pin is low at power up. These commands allows the console to be used with RS232 signals without a converter and allows the use of a PICAXE style programming cable.
- CFUNCTION, I2C, PEEK and POKE will accept arrays specified by a pair of empty of brackets. eg: arg(). For backwards compatibility the old standard of specifying the first element (ie, arg(0)) is still supported.
- Extended the POKE command and PEEK() function to use 64-bit integer addresses. Also, the PEEK() function can now return the address of a variable in memory in addition to the contents of that address.
- PEEK and POKE now validate the memory address to reduce the chance of the operation causing a MIPS memory exception.
- You can now pass arrays to subroutines or functions. In the argument supplied and in the parameter list the array is represented by an empty pair of brackets. eg: arg(). The array will be passed by reference so any changes to it in the subroutine or function will change the array passed. See the section "Passing Arrays" in the User Manual.
- END IF and ELSE IF can be used as alternatives to ENDIF and ELSEIF respectively
- The TIMER function will now count up for over 200 million years before rolling over to zero (it is now a 64-bit counter).
- Extended the HEX\$(), OCT\$() and BIN\$() functions to take an optional second argument which specifies the minimum number of characters in the returned string. Numbers with less than this number of digits will be padded with zero as the leading character(s).

- The SPI function can now send/receive data in 32 bit blocks (in addition to 8 and 16 bits).
- Added the SPI WRITE and SPI READ commands for high speed transfer of bulk data over a SPI communications channel.
- The DS18B20() function will now return a temperature of 1000 (obviously invalid) if the sensor does not respond or shows an error. Previously the program would abort with an error message.
- Using the break key (normally Ctrl-C) in the editor will now prompt the user and ask if they want to abandon their edits (ie, will act the same as the escape key).
- Changed OPTION PIN to use eight digits and also introduced a three second delay after a PIN has been entered. This makes it much harder for a brute force attack on the PIN to succeed. Also, the PIN can be set to 99999999 which will permanently lock the console and cannot be removed.
- The MEMORY command will now only show details of the memory used by saved variables and CFunctions if these features have been used. This is to reduce screen clutter.
- Increased the maximum allowable number of sub/functions (combined) from 32 to 100.
- The type of a user defined function can be specified by adding AS <type> to the end of the function's definition. For example:  

```
FUNCTION FUNNAME(arg1, arg2) AS INTEGER
```
- The type of an argument to a user defined function or subroutine can be specified by adding AS <type> to the end of the argument's definition. For example:  

```
SUB FUNNAME arg1 AS INTEGER, arg2 AS STRING
```
- To prevent a common type of programming error variables with the same name but different types are no longer supported. ie, var = 123 : var\$ = "abc" will now cause an error.
- The space allocated to the VAR SAVE command is now 2KB.
- Added CPU RESTART command to force a restart of the processor.
- Changed the string returned by the automatic variable MM.DEVICE\$ to "Micromite MkII". This is because V4.6 and later will only run on the Micromite MkII (ie, PIC32MX170F256).
- A suitable message will be displayed (rather than the normal power on banner) if the watchdog timer caused a restart.
- When turning a pin off using the SETPIN command you must use either the command SETPIN x, OFF -or- SETPIN x, 0. Previously you could use a variable set to zero but this facility caused difficult to locate errors when the mode for a pin was accidentally misspelt.
- Before starting I<sup>2</sup>C communications the I2C OPEN command will first check for a stuck slave and will try to clear it by pulsing the clock line.
- The I<sup>2</sup>C commands will now accept integers for send data, receive data and receive data length.
- SAVE VAR without any arguments will erase the saved variable space.
- The NEW command will now also erase any saved variables.

- Fixed an issue with the I<sup>2</sup>C slave receive buffer not being cleared when the I2C slave was restarted after previous activity.  
See: [http://www.thebackshed.com/forum/forum\\_posts.asp?TID=6599&PN=1](http://www.thebackshed.com/forum/forum_posts.asp?TID=6599&PN=1)  
and [http://www.thebackshed.com/forum/forum\\_posts.asp?TID=6527&PN=1&TPN=2](http://www.thebackshed.com/forum/forum_posts.asp?TID=6527&PN=1&TPN=2)  
Note that CTRL-C does not close a communications channel because CONTINUE might be used to resume running the program. When RUN or NEW is used all communications and I<sup>2</sup>C activity will be stopped.
- Fixed a bug in the KEYPAD command which prevented the editor from being run after the KEYPAD command reported an invalid pin error.
- Fixed a bug which caused the PWM command to not correctly configure the relevant PWM pins as outputs.
- Fixed two bugs which caused strange results when functions were nested in the command line of a function. Functions can now be used in the arguments provided to a subroutine or function and can be nested within each argument to an unlimited level.
- Fixed a bug which prevented the use of expressions in the arguments to PEEK().
- Updated the manual to describe the new features. The manual now includes a full bookmark listing which can be displayed in most PDF viewers and used to jump to a particular topic.

## Change log for Micromite MMBasic Ver 4.5D

- Added the PULSEIN function to measure the width of an input pulse.
- The DS18B20() function now always generates an error if the sensor is disconnected (previously it could return a reading of -127.938 in some cases).
- The XMODEM receive function will now wait for the sender to stop sending data before reporting an out of memory error. This means that the error message will be visible in the terminal emulator window.
- Fixed a bug in the DS18B20() function that caused erroneous negative readings.
- Fixed a bug which caused the processor to reboot when the EOF() function was used.
- Corrected a bug which could cause a strange behaviour of MMBasic when SETPIN was used on pin 11 or greater. The effect was intermittent and rare.
- Fixed an error where the PORT() function returned the input pins in reverse order.
- Updated the manual to describe the PULESIN function.

## Change log for Micromite MMBasic Ver 4.5C

- Corrected a bug which allowed the RND() function to return the number 1 (the specifications state that it must return a number from zero to less than 1).
- Fixed a bug that caused an error when the LENGTH keyword was used when defining a string array using the LOCAL command.
- Fixed a bug that kept resetting the variable used in the KEYPAD command to -1.
- Corrected a rare issue caused by some low cost USB-serial adapters that could cause V4.5 of the firmware to partially erase itself when there was a glitch in the power during start up. In that case the only solution was to re program the chip using a PIC32 programmer.

Note: V4.5 was the first release of MMBasic specifically for the Micromite